

Fluid Management

Technical Support

How to install ColorPro 4.x.

PRODUCT(S)

All non-manual dispensers using ColorPro

PURPOSE

This instruction is for all customers who need to install the ColorPro 4.x. program onto a corresponding Fluid Management dispensing machine. If you would like the new program to restore your original machine configuration/calibration, back-up existing files.

INSTRUCTIONS

1. Back-up existing machine configuration/calibration files on your current dispenser. By backing up these files, you ensure that the settings for your machine remain the same. (NOTE: if you do not have access to your old PC or these files, move on to step 2)
 - a. Locate the **This PC** shortcut on your desktop or search for **This PC** by clicking on the Windows home icon
 - b. Open the **Windows (C:)** drive
 - c. Open the **Program Files** folder
 - i. On the (64bit) ColorPro PC, open **Program Files (x86)**
 - ii. On the (32bit) ColorPro PC, open **Program Files**
 - d. Open the **Fluid Management** folder
 - e. Open the **IDDdvs** folder
 - f. Copy **fmLib** folder and paste it onto the desktop screen and/or a flash drive
 - g. In the **IDDdvs** folder, copy the **mcl.ini**
 - h. Paste it into the desktop and/or a flash drive
2. Insert flash drive
3. Open removable disk

4. Copy and Paste **SW1701** onto the desktop
5. Click on **SW1701** on the desktop and select **setup.exe**
6. ColorPro will install prerequisites in about 10-15 minutes
7. When the ColorPro install wizard appears, click **Next**
8. After ColorPro installs, click **Next** when prompted
9. Click **Finish**
10. Return to the Windows Desktop Screen and check for the ColorPro icon
11. Install **fmlib** files (NOTE: continue with this step only if the machine configuration/calibration was backed up. If not, continue to step 12
 - a. From flash drive or desktop, open the **fmlib** folder
 - b. Copy the **.prp** files and paste them into the **fmlib** folder on the C: drive
 - i. On the (64bit) ColorPro PC, follow the path **C:\Program Files (x86)\Fluid Management\IDDdvx\FMLIB**
 - ii. On the (32bit) ColorPro PC, follow the path **C:\Program Files\Fluid Management\IDDdvx\FMLIB**
 - c. From the flash drive or desktop, copy the **mcl.ini** folder and paste it into the **IDDdvx** folder on the C: drive
 - i. On the (64bit) ColorPro PC, follow the path **C:\Program Files (x86)\Fluid Management\IDDdvx**
 - ii. On the (32bit) ColorPro PC, follow the path **C:\Program Files\Fluid Management\IDDdvx**
 - d. Restart the computer
12. To confirm that ColorPro works, open the program and do a command (dispense, purge, or agitate)
13. If errors occur or the program does not open, contact the Fluid Management Technical Support Team at 1.800.462.2466