


ACCUTINTER 1600 SPARE PARTS MANUAL




*Rev(B)
December 4, 2017*

AT 1600 SPARE PARTS QUICK REFERENCE


Page	Reference	Part #	Description	Notes
<u>1</u>	<u>A</u>	32437	Canister Lid	
<u>1</u>	<u>B</u>	38089	Canister only, 3 liter	Replacement 3 Liter canister WITHOUT a pump
<u>1</u>	<u>C</u>	38085	Pump only, Dual Chamber	Standard Speed Replacement Pump (Dual Chamber / Single Stack)
<u>1</u>	<u>D</u>	37265	Agitator Motor	
<u>1</u>	<u>E</u>	29821	Tubing from Pump to Nozzle	5/16" Tubing (Refer to Appendix)
<u>1</u>	<u>F</u>	26640	Connector, Pump-to-Nozzle Tubing	1/2" to 5/16" Straight through quick connect (Refer to Appendix)
<u>1</u>	<u>G</u>	35353	Connector, Nozzle Tubing-to-Nozzle Block	5/16" to 1/4" Straight through quick connect (Refer to Appendix)
<u>2</u>	<u>A</u>	35796	Manual Nozzle Closer Assembly	Contains the nozzle cup
<u>2</u>	<u>B</u>	35593	Cup and Gasket, Nozzle Closer	
<u>2</u>	<u>C</u>	36844	Nozzle Cup Liner Kit	10 Pack (Refer to Appendix)
<u>3</u>	<u>A</u>	83252702RH	Switch, Abort	
<u>3</u>	<u>B</u>	35473	Spring, Manual Nozzle Closer	
<u>3</u>	<u>C</u>	81301101RHK	Sensor Switch, Can In Place	
<u>3</u>	<u>D</u>	29687	PCB, Locator Light	Contains 3 leds - 120 degrees apart
<u>3</u>	<u>E</u>	35390	Tube Nozzle Assembly	Includes quick connects p/n: 35353 installed on each tube (Not Shown) (Refer to Appendix)
<u>4</u>	<u>A</u>	87140039RH	PCB, All-In-One (AIO PCB)	
<u>4</u>	<u>B</u>	37848	PCB, Amp Reduction	
<u>5</u>	<u>A</u>	83820124RH	Power Supply	
<u>5</u>	<u>B</u>	81512205RH	Reset Switch	
<u>5</u>	<u>C</u>	35719	Power Cord	
<u>5</u>	<u>D</u>	80307312RH	Terminal Block	(Refer to Appendix)
<u>5</u>	<u>E</u>	87600136RH	Line Filter	(Refer to Appendix)
<u>5</u>	<u>F</u>	36841	Complete Wire Harness	No Image is Available
<u>6</u>	<u>A</u>	29821	Tubing from Pump to Nozzle	5/16" Tubing
<u>6</u>	<u>B</u>	26640	Connector, Pump-to-Nozzle Tubing	1/2" to 5/16" Straight through quick connect
<u>6</u>	<u>C</u>	35353	Connector, Nozzle Tubing-to-Nozzle Block	5/16" to 1/4" Straight through quick connect
<u>6</u>	<u>D</u>	35390	Tube Nozzle Assembly	Includes quick connects p/n: 35353 installed on each tube
<u>6</u>	<u>E</u>	36844	Nozzle Cup Liner Kit	10 Pack
<u>6</u>	<u>F</u>	80307312RH	Terminal Block	
<u>6</u>	<u>G</u>	87600136RH	Line Filter	
<u>6</u>	<u>H</u>	29767	Needle, Pick, Nozzle Cleaner	
<u>6</u>	<u>I</u>	37093 37094	Kit, Sponge, Qty 6 Kit, Sponge, Qty 12	1.7" diameter, .75" thick




	Part #	Description	Notes
A	32437	Canister Lid	
B	38089	Canister only, 3 liter	Replacement 3 Liter canister WITHOUT a pump
C	38085	Pump only, Dual Chamber	Standard Speed Replacement Pump (Dual Chamber / Single Stack)
D	37265	Agitator Motor	
E	29821	Tubing from Pump to Nozzle	5/16" Tubing (Refer to Appendix)
F	26640	Connector, Pump-to-Nozzle Tubing	1/2" to 5/16" Straight through quick connect (Refer to Appendix)
G	35353	Connector, Nozzle Tubing-to-Nozzle Block	5/16" to 1/4" Straight through quick connect (Refer to Appendix)




	Part #	Description	Notes
A	35796	Manual Nozzle Closer Assembly	Contains the nozzle cup
B	35593	Cup and Gasket, Nozzle Closer	
C	36844	Nozzle Cup Liner Kit	10 Pack (Refer to Appendix)



	Part #	Description	Notes
A	83252702RH	Switch, Abort	
B	35473	Spring, Manual Nozzle Closer	
C	81301101RHK	Sensor Switch, Can In Place	
D	29687	PCB, Locator Light	Contains 3 leds - 120 degrees apart
E	35390	Tube Nozzle Assembly	Includes quick connects p/n: 35353 installed on each tube (Not Shown) (Refer to Appendix)




	Part #	Description	Notes
A	87140039RH	PCB, All-In-One (AIO PCB)	
B	37848	PCB, Amp Reduction	



	Part #	Description	Notes
A	83820124RH	Power Supply	
B	81512205RH	Reset Switch	
C	35719	Power Cord	
D	80307312RH	Terminal Block	(Refer to Appendix)
E	87600136RH	Line Filter	(Refer to Appendix)
F	36841	Complete Wire Harness	No Image is Available




A



B


C




D



E




F



G



H



I

	Part #	Description	Notes
A	29821	Tubing from Pump to Nozzle	5/16" Tubing
B	26640	Connector, Pump-to-Nozzle Tubing	1/2" to 5/16" Straight through quick connect
C	35353	Connector, Nozzle Tubing-to-Nozzle Block	5/16" to 1/4" Straight through quick connect
D	35390	Tube Nozzle Assembly	Includes quick connects p/n: 35353 installed on each tube
E	36844	Nozzle Cup Liner Kit	10 Pack
F	80307312RH	Terminal Block	
G	87600136RH	Line Filter	
H	29767	Needle, Pick, Nozzle Cleaner	
I	37093 37094	Kit, Sponge, Qty 6 Kit, Sponge, Qty 12	1.7" diameter, .75" thick